

Classification:

EL08-036

Reference:

ITB09-002

Date: COPYRIGHT© NISSAN NORTH AMERICA, INC.

January 6, 2009

BCM INSPECTION AND CONFIGURATION DURING REPLACEMENT

APPLIED VEHICLES: All models equipped with a configurable BCM

SERVICE INFORMATION

- The "BCM Inspection and Configuration During Replacement" Service Procedure will no longer be available in Technical Service Bulletins.
- The step-by-step procedure is now available only in the CONSULT-III Operation Manual.
- For security reasons, the Manual is blocked from print functions.

To Locate this Service Procedure within the CONSULT-III Operation Manual:

1. From the Main Menu page in ASIST, select **INFO. Tool Box**.
2. Select **Specialty Tools**.
3. Select **CONSULT-III Operation Manual**.
4. From the Manual Selection window, select **CONSULT-III Operation Manual**.
5. Select your language preference.
6. Select **Repair** from the navigation bar on the left side of the screen.
7. Select **Configuration** under Electronic Repair - System Selection.

Infiniti Bulletins are intended for use by qualified technicians, not 'do-it-yourselfers'. Qualified technicians are properly trained individuals who have the equipment, tools, safety instruction, and know-how to do a job properly and safely. NOTE: If you believe that a described condition may apply to a particular vehicle, DO NOT assume that it does. See your Infiniti dealer to determine if this applies to your vehicle.